Federal Aviation Administration, DOT

- (2) Have a reliable, approved personnel carrying device system that has the structural capability and personnel safety features essential for external occupant safety;
- (3) Have placards and markings at all appropriate locations that clearly state the essential system operating instructions and, for the personnel carrying device system, the ingress and egress instructions:
- (4) Have equipment to allow direct intercommunication among required crewmembers and external occupants; and
- (5) Have the appropriate limitations and procedures incorporated in the flight manual for conducting human external cargo operations.
- (d) The critically configured jettisonable external loads must be shown by a combination of analysis, ground tests, and flight tests to be both transportable and releasable throughout the approved operational envelope without hazard to the rotorcraft during normal flight conditions. In addition, these external loads must be shown to be releasable without hazard to the rotorcraft during emergency flight conditions
- (e) A placard or marking must be installed next to the external-load attaching means clearly stating any operational limitations and the maximum authorized external load as demonstrated under §27.25 and this section.
- (f) The fatigue evaluation of §27.571 of this part does not apply to rotor-craft-load combinations to be used for nonhuman external cargo except for the failure of critical structural elements that would result in a hazard to the rotorcraft. For rotorcraft-load combinations to be used for human external cargo, the fatigue evaluation of §27.571 of this part applies to the entire quick release and personnel carrying device structural systems and their attachments.

[Amdt. 27–11, 41 FR 55469, Dec. 20, 1976, as amended by Amdt. 27–26, 55 FR 8001, Mar. 6, 1990; Amdt. 27–36, 64 FR 43019, Aug. 6, 1999]

MISCELLANEOUS

§ 27.871 Leveling marks.

There must be reference marks for leveling the rotorcraft on the ground.

§ 27.873 Ballast provisions.

Ballast provisions must be designed and constructed to prevent inadvertent shifting of ballast in flight.

Subpart E—Powerplant

GENERAL

§ 27.901 Installation.

- (a) For the purpose of this part, the powerplant installation includes each part of the rotorcraft (other than the main and auxiliary rotor structures) that—
 - (1) Is necessary for propulsion;
- (2) Affects the control of the major propulsive units; or
- (3) Affects the safety of the major propulsive units between normal inspections or overhauls.
- (b) For each powerplant installation—
- (1) Each component of the installation must be constructed, arranged, and installed to ensure its continued safe operation between normal inspections or overhauls for the range of temperature and altitude for which approval is requested;
- (2) Accessibility must be provided to allow any inspection and maintenance necessary for continued airworthiness;
- (3) Electrical interconnections must be provided to prevent differences of potential between major components of the installation and the rest of the rotorcraft;
- (4) Axial and radial expansion of turbine engines may not affect the safety of the installation; and
- (5) Design precautions must be taken to minimize the possibility of incorrect assembly of components and equipment essential to safe operation of the rotor-craft, except where operation with the incorrect assembly can be shown to be extremely improbable.
- (c) The installation must comply with—
- (1) The installation instructions provided under §33.5 of this chapter; and